

Application Note

AN #: 247

DATE: 18-Feb-05

Page 1 of 1

PYRAMID MODEL #: SVR-200 / SVR-250 / SVR-300
RADIO MODEL: Motorola CDM 1550 /w Scholer Johnson PassPort Board

APPROVAL INITIALS

ENGINEER

DEPT. HEAD

Connections:	SVR	Function	Radio
	Black/Shield	Ground	Accessory Connector Pin 7
	White	Tx Audio Out	Accessory Connector Pin 2
	Blue	Remote enable/disable	External Switch To Ground
	Green	PTT Out	Accessory Connector Pin 3
	Red	Switched B+	Accessory Connector Pin 13
	Yellow	Rx Audio In	Accessory Connector Pin 11
	Violet	COR	Accessory Connector Pin 4
	Brown	Local Mic In	N/C
	Grey	On Air Detect	Accessory Connector Pin 8

SVR	JP1	[-]	Remote Enable	SVR	Mobile COR Polarity:	Low
Jumpers:	J1	[Out]	Tx audio level	Program:	Mobile Type:	Conv./
	J2	[Out]	Tx audio impedance		Trunk	
	J4	[Out]	Local mic audio loop		On-Air Polarity:	Low
	J5	[Out]	Local mic PTT loop		Tx Audio Response:	De-emp
	J6	[Out]	Local mic sensitivity			
	J7	[Out]	Receive sensitivity			
	J8	[+]	Pull up resistor			
	J9	[Out]	COR Pull up resistor			

Additional Modifications (SVR-200 / SVR-250 / SVR-300):

Additional Modifications (Radio):

- From the Motorola CPS --> **Radio Configuration**, program the **Accessory Pins**:
 - Pin #3 - Option board 1 (input) *Active Low*
 - Pin #4 - Option board 1 (output) *Active Low*
 - Pin #8 - Option board 2 (output) *Active Low*
- From the Motorola CPS --> **Radio Configuration**, program the **Accessory Configuration**:
 - RX Audio Type = Flat Audio
 - Ext. PTT Audio Source = Ext Mic Audio
- In the Scholer-Johnson RSS --> **Radio Globals**, program the **Accessory Connector**:
 - Option Board Input 1 = PTT
 - Option Board Output 1 = Tone Busy
 - Option Board Output 1 = Tx Active

Note: Local Mic. Repeat is not supported by the CDM-1250/1550 Radio.