



Heavy Duty Front Basket Installation Instructions

1. Attach the basket to the front accessory mount using the bike's included screws. Use the included washers as shown.
2. Use the included zip ties to attach the bike's cables to the basket to avoid interference with steering. Leave some slack in the zip tie.



Notice: The basket has a payload capacity of 50 Pounds (22 kg).

Juiced Riders Electric Bikes

1055 Bay Blvd, Suite F
Chula Vista, CA 91911
Tel: 619-746-8877
www.JuicedRiders.com
mail@juicedriders.com