

[Click here to print this page.](#)

Installation Tips

When installing lattice, all edges of panels should be well supported, preferably continuously and to a depth of at least 1/2". We recommend securing into a framed opening, using Woodway mouldings (or sandwiching with 3/4" stop) and a bead of construction adhesive.

When cutting lattice, cut from the side of the panel with visible fasteners. Support the panel from the cut line and on outer edges to avoid tearing lath.

Local codes must be followed particularly with regard to railings on porches, balconies and stairs. Heavy lattice is recommended for such installations, and concern will be primarily on the detailing of the support system for the lattice.

It is recommended that finishes be applied prior to installation as the numerous openings and intersections of lath make coating application difficult once the panels are in place. Coatings should be applied early to minimize effects of weathering. Woodway Lattice requires very little maintenance beyond periodic refinishing depending on climate and exposure.

[CLOSE WINDOW](#)