

SecureFit360® Liner Bags (LBSF360)

Fits Surface/ Wall Mounted Sanitary Napkin Disposal Units

Stainless Steel, Metal and Plastic

Bobrick, Bradley, Impact, Hospital Specialty, Continental,
Rochester Midland, Rubbermaid, ASI



Installation Instructions

1. To remove bag from bundle, place one hand on die cut section while gently pulling up on bag to separate.



2. Insert bag into receptacle with strap hanging in front. (Optional: Open perforation to slide over lid)



3. Open bag slightly, then fold bag over front and sides of receptacle



4. Pull gently on hanging strap to fit around bottom of receptacle. Adjust bag as needed to ensure proper fit.



5. To remove, release and pull up on liner to discard contents.

