

## INSTALLATION INSTRUCTIONS

### Scensibles® SecureFit360® Liner Bags

#### ITEM# LBSF500

Recommended for wall-mounted feminine hygiene

waste receptacles: CDSS, CDWM, ND-1E, ND-1W, 250-201W

Size: 13" x 14" with 6" strap

Case Pack: 500/case



#### STEP 1

To remove bag from bundle, place one hand on die cut section while gently pulling up on bag to separate.



#### STEP 2

Insert the body of the bag into the receptacle with strap hanging in front. Open bag slightly, then fold back over front and sides of receptacle.



#### STEP 3

Pull gently on hanging strap to fit around bottom of receptacle. Adjust bag as needed to ensure proper fit.



#### STEP 4

To remove, pull up on strap around the bottom to discard contents.

