



## Directions: (continued)

- Do the following to verify that Dragon is correctly strung. Slowly turn the slotted wheel counter-clockwise until the upper drive string loop is straight out from the front slot at about 8 o'clock. Hold it in this position. The patterning wheels should have turned clockwise and the front one will still be turning. The front arm should be pointing between 2 and 3 o'clock, and the back arm to about 5 o'clock.
- Now slowly turn the slotted wheel clockwise until the upper drive string loop is straight out from the rear slot at about 10 o'clock. Hold it in this position. The rear patterning wheel should have turned counter-clockwise with the front wheel continuing it's previous clockwise motion. The rear arm should now be pointing between 2 and 3 o'clock, and the front arm to about 5 o'clock.

### To Wind

- Turn the drive pulley wheel counter-clockwise 20 turns.

### To Start

- If Dragon does not start immediately after winding, gently turn the slot wheel 1/2 turn counter-clockwise.

### Guarantee

- Workmanship and materials are unconditionally guaranteed. I will repair the sculpture without charge if it is returned post paid.
- I will charge a reasonable repair fee if the sculpture was damaged by misuse.

### To move or repack the sculpture:

- Tape the upper drive string in place to the slot wheel before unlooping it from the patterning wheels. Tape the loop of string into the slot wheel where it emerges from the front and rear slots and several other places along the rim of the wheel. Wrap the extra string around the knob on the arms. Tape the arm strings directly to the slot wheel. Put spacers between patterning wheels to prevent brass from bending.

