



**RF Systems, Inc.**  
 26H World's Fair Drive  
 Somerset, NJ 08873  
 (732) 563-1144  
 www.dsirf.com

## Model UCS-1000 Universal Camera Controller

### Supervisor Mode

Permits access to the camera menu tree to adjust all camera parameters

**Menu:** Toggles the onscreen menu

**Item Up:** Steps Upward thru the onscreen menu

**Item Down:** Steps Downward thru the onscreen menu

**Left:** Steps Left thru the selected parameter menu

**Right:** Steps Right thru the selected parameter menu

Switch Illuminates only in Supervisor Mode

### Preset Functions

#### Playback Procedure:

- 1) Press knob to activate Playback Presets
- 2) Rotate knob to the desired preset
- 3) Press knob to execute playback preset

#### Record Procedure:

- 1) Press Record button to activate recording Presets
- 2) The record switch will illuminate  
 (Note that there is a built in delay to prevent accidental activation)
- 3) Rotate knob to the desired preset
- 4) Press Record button to store preset

### Zoom Control

Toggle action zooms camera Wide or Tele

### Iris Control

Adjusts the Iris when in Manual mode

To select Manual mode depress the On/Off switch until the switch is illuminated.  
 (Note that there is a built in delay to prevent accidental activation)

Adjust the Iris knob for the desired iris opening

Operates with Supervisor mode on or off

### Camera Functions

Executes Camera functions  
 All switches are momentary and operate with Supervisor mode on or off

### System Controls

Executes system functions  
 These are toggle functions. Press once for on and again for off  
 The Wiper switch, when activated, also automatically washes the view window for 1.5 seconds  
 All switches are momentary and operate with Supervisor mode on or off

### Supervisor eKey

Application of the Supervisor iButton key to the reader will activate the Supervisor Menu  
 Use the Selector knob to select the Supervisor Mode  
 Depress the Selector knob to select your choice  
 The Menu switch illuminates to verify the Supervisor Mode is on

### Selector

Selects the desired Site Control channel and Supervisor mode selections

#### Site or Supervisor Mode Selection Procedure:

- 1) Press knob to bring up menu on the display
- 2) Rotate knob to desired choice
- 3) Press knob to select choice

### Display

Displays all system data

