

#### Cedar ■ Pine ■ Plywood ■ Hardwoods ■ Wood Coatings ■ Composite Deckings

11711 E. EIGHT MILE ROAD • PO BOX 1085 • WARREN • MICHIGAN • 48090 PHONE: 586.773.1200 • FAX: 586.773.9611 • E-MAIL: info@cjlinklumber.com • WEB: www.cjlinklumber.com

#### **RESTORE-A-DECK Deck Stain Stripper**

Here are the tools for the job: (available separately)

- Two Gallon Pump Up Sprayer
- Garden Hose With Pressure Spray Attachment
- Wraparound protective eye wear and gloves
- 5 gallon empty bucket
- Stirring stick

#### **Optional Equipment:**

Pressure Washer

#### **TEST AREA**

Always prepare a test patch in an inconspicuous area prior to full application. This will indicate the performance and suitability of the product for the substrate.

### **PREPARATION**

Project surfaces must be dry & warm; above 50 degrees Fahrenheit (10 degrees Celsius). **RESTORE-A-DECK Deck Stain Stripper** may harm bare metal or painted surfaces. Pre-wet vegetation. Direct exposure may burn foliage but rinsing residue will not harm plants or roots.

# <u>APPLICATION PROCEDURES</u>

Using heavy duty rubber gloves, mix 6-10 ounces of Deck Stain Stripper per gallon of water until all crystals have dissolved (2 lbs. of **RESTORE-A-DECK Deck Stain Stripper** makes 5 liquid gallons).

**Pump Sprayer (Difficult Stains):** For difficult to remove finishes, apply liberally to deck/wood coating to be removed at 100-200 feet per gallon with pump sprayer,

**Down Stream Injector:** Attach down stream injector to pressure washer and insert suction tube into pre-mixed product. Make sure product is flowing through tubing when applying. You must use a chemical tip or wand to apply. Apply liberally at 300 feet per gallon. Multiple applications may be needed for hard to remove finishes.

#### <u>WASH</u>

Allow **RESTORE-A-DECK Deck Stain Stripper** to soften or dissolve the coating for 10-30 minutes. Test readiness by scrubbing small area. If



finish comes off then you are ready to proceed. Heavy scrub or lightly pressure wash off the coating. Repeat if needed for difficult to remove areas. Rinse away all dirt and grime from deck when done. Neutralize and brighten wood with **RESTORE-A-DECK Step 2 Brightener**.

#### **PRECAUTIONS**

**Poison:** Keep out of reach of children. Prolonged contact may cause burns. Avoid ingestion or contact with skin or eyes. Wear rubber gloves and goggles or safety glasses with side shields. Project surfaces are extremely slippery.

#### **FIRST AID**

**Eyes:** This product is destructive to eye tissues on contact. Immediately flush eyes with large amounts of water for at least 15 minutes. SEEK MEDICAL ATTENTION IMMEDIATELY.

**Skin:** Immediately wash skin with large amounts of water. Remove contaminated clothing and shoes; wash before reuse. Get medical attention if irritation persists after washing.

## **HINTS**

**RESTORE-A-DECK Deck Stain Stripper** will strip oil & common latex semi-transparent deck finishes. Scrub lightly where required. Use stiff brush or floor broom to help remove residue. Work in the direction of the grain to minimize "grain raising" on wood surface. Rinse wood in direction of grain with water; using a garden hose or 500-1200 PSI power washer. A power washer will eliminate the need for scrubbing.

#### **DISPOSAL**

Dispose remaining product in accordance with applicable environmental regulations.