

Restore-A-Deck Wood Brightener

Product Data Sheet

MANUFACTURER:

RAD OPW, LLC
2388 Franklin Rd
Bloomfield Hills, MI 48302
866-856-3325
www.restore-a-deck.com



DESCRIPTION

Restore-A-Deck Wood Brightener is a biodegradable, powdered concentrate that is mixed with water to brighten and restore the natural beauty of all species of exterior wood. This product excels at brightening, removing rust stains, and tannin stains caused by fallen leaves. Restore-A-Deck Wood Brightener is a safe, product that will not only will brighten and neutralize the surface of the wood, creating an ideal surface that is ready to be stained. This product is step 2 of a 3 step system.

WHERE TO USE

Restore-A-Deck Wood Brightener is intended for use on all types of weathered, exterior wood surfaces including decks, fences, siding, outdoor furniture, gazebos and playsets.

Recommended for surface preparation prior to initial application of semi-transparent finishes and stains. Product can be used as a cleaner and brightener for redwood, or as a neutralizer to further brighten wood species, like pine, that have been cleaned with Restore-A-Deck Wood Cleaner or stripped with Restore-A-Deck Stain Stripper. For lasting protection of your exterior

wood, after using Restore-A-Deck Wood Brightener, treat the surface with Restore-A-Deck Premium Wood Stain.

Note: Restore-A-Deck Wood Brightener is not formulated to remove intact paint, stain, or clear finishes and may dull painted and metal surfaces if not quickly rinsed.

ADVANTAGES

- Neutralizes stain strippers
- Brightens and restores wood surfaces
- Improves absorption of wood stains

APPLICATION

Mix Well: Mix 2/3 to 1 cup of the powdered Brightener per gallon of water. Ensure all crystals have dissolved. A full 2lb bag will make 5 liquid gallons. Mix well in a plastic container.

Apply: Thoroughly wet surface and ALL surrounding vegetation with water before application. Apply Restore-A-Deck Wood Brightener solution to wet wood with sprayer, brush, or mop. **Note:** Scrubbing is unnecessary if used after cleaning or stripping wood with Restore-A-Deck Wood Cleaner or Stain Stripper. Let solution stand for 5 - 15 minutes, keeping wet with additional solution if necessary. On vertical surfaces begin applying solution at the bottom and work to the top. Application may be repeated if desired.

Rinse: Rinse wood and all surrounding vegetation thoroughly by flooding area with water from garden hose. Rinse vertical surfaces from bottom up to avoid streaking.

Coverage: 100-200 square feet per gallon (when mixed) depending on surface coating to be removed. A full bag when mixed will make 5 gallons and cover 500-1000 square feet.

Cleanup: Clean tools and equipment immediately after each use with soap and water.

PRECAUTIONS

Keep out of reach of children. Do not take internally. Avoid contact with eyes and skin. Avoid breathing mist. Close container tightly after each use. Do not re-use containers. Store only in original container. The use of chemical splash goggles and rubber gloves is recommended when handling this product. Accumulation of product on ladders, scaffolding, decks, etc. may result in a slippery surface. Contains oxalic acid. Do not mix Restore-A-Deck Wood Brightener with Restore-A-Deck Deck Wood Cleaner, chlorine bleach, or other chemicals.

FIRST AID

IF INHALED: Ensure fresh air breathing. Allow the victim to rest. In case of breathing difficulties, administer oxygen. Seek medical attention immediately. **IF SWALLOWED:** Rinse mouth with water (only if the person is conscious). Do NOT induce vomiting unless directed to do so by medical personnel. Immediately call a POISON CENTER or doctor/physician. Obtain emergency medical attention. **FOR SKIN CONTACT:** Rinse using water. Remove contaminated clothes. Wash skin thoroughly with mild soap and water. If skin irritation persists, seek medical attention. **FOR EYE CONTACT:** Immediately flush eyes thoroughly with water for at least 15 minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Seek medical attention immediately.

For additional information for this product, consult the Product Data Sheet or Safety Data Sheet available at www.restore-a-deck.com.

LIMITED WARRANTY

Our recommendations for use of this product are based upon tests believed to be reliable. Since field conditions vary widely, the user must determine the suitability of the product for the particular use and specific method(s) of application. Due to the fact that RAD OPW LLC has no control over surface preparation and application methods, no guarantee as to results is offered, expressed or implied. RAD OPW LLC warrants this product to be free from manufacturing defects.

RAD OPW LLC liability shall be limited in all events to supplying enough product to re-treat the specific areas to which defective product was applied. This warranty does not include the cost of labor application. RAD OPW, LLC shall not have any other liability including direct, incidental, or consequential damages. Some states do not allow the exclusion of incidental or consequential damages, so this limitation may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Shelf Life: 36 months

PACKAGING

Available in 2 LBS recyclable plastic bags/containers.

TRANSPORT AND HANDLING

Restore-A-Deck Wood Brightener is not considered hazardous under Department of Transportation regulations. Do not stack pallets. **Keep from freezing.**