

Restore-A-Deck Wood Cleaner

Product Data Sheet

MANUFACTURER

RAD OPW, LLC
2388 Franklin Rd
Bloomfield Hills, MI 48302
866-856-3325
www.restore-a-deck.com



DESCRIPTION

Restore-A-Deck Wood Cleaner is a powdered concentrate that is mixed with water. It safely cleans and restores the natural beauty of exterior wood. This product also cleans weathered composite lumber, removing mold, mildew and algae along with the silver-gray color that can develop over time. Restores all wood surfaces to their original appearance. Restore-A-Deck Wood Cleaner will not harm wood fibers, pets, grass, or most plants. This product is step 1 of a 3 step system.

USES

Restore-A-Deck Wood Cleaner removes dirt, grime, mold and mildew stains, and weathered graying from horizontal and vertical wood surfaces. It is recommended for surface preparation prior to application or reapplication of wood stains. For best results use Restore-A-Deck Wood Stains.

ADVANTAGES

- Removes stains caused by mold and mildew
- Removes wood graying caused by UV rays
- Removes existing, weathered stains
- Removes dirt and debris

Limitations: Restore-A-Deck Wood Cleaner will slightly darken wood. Use Restore-A-Deck Wood Brightener to restore all wood to its original color and as a neutralizer to further brighten other wood species that have been cleaned with Restore-A-Deck Wood Cleaner.

DIRECTIONS FOR USE

Using heavy duty rubber gloves, mix 2/3 to 1 cup of the powdered stripper per gallon of water. Ensure all crystals have dissolved. A full 2lb bag will make 5 liquid gallons.

STEP 1 MIX: Mix with water and stir thoroughly until powder is mostly dissolved. Solution should be used within six hours of mixing.

STEP 2 APPLY: Horizontal Surfaces: Dampen surface with water before application. Apply Restore-A-Deck Wood Cleaner solution with sprayer, brush, car wash type brush, working on small areas, (100-200 sq. ft.) at a time. If using a sprayer, to avoid clogging, do not mix directly in a pump sprayer but in a separate bucket.

Vertical surfaces: Dampen surface with water before application. Apply with a sprayer working on small areas at a time. Begin at the bottom and work to the top.

STEP 3 Scrub or Pressure Wash:

Using a power washer (1500-2000 psi) will eliminate the need for scrubbing. However, particular care should be taken with a power washer to avoid damaging wood.

Horizontal Surfaces: Let solution stand approximately 15-20 minutes, keeping area wet with additional Restore-A-Deck Wood Cleaner solution. Thoroughly scrub with a stiff, short bristle broom or brush.

Vertical Surfaces: Let solution stand approximately 15-20 minutes, keeping surfaces wet with additional solution. Thoroughly scrub with a stiff, short bristle broom or brush working from bottom to top. Restore-A-Deck Wood Cleaner will open wood pores and some raising of wood fibers may occur.

STEP 4 RINSE: Rinse thoroughly with water from hose or pressure washer using lowest pressure that cleans without damaging the wood. Repeat steps 2-4 on next small area. Rinse cleaned area of vertical surfaces to avoid streaking as work progresses.

Neutralize and brighten wood with Restore-A-Deck wood brightener immediately after cleaning, while wood is still wet. Any cleaner not neutralized and thoroughly rinsed will cause poor coating adhesion

Allow wood surfaces to thoroughly dry before applying Restore-A-Deck Wood Stains.

COVERAGE: One container of Restore-A-Deck Wood Cleaner will make 5 gallons of cleaning solution and cover approximately 750-1,000 sq. ft. depending on surface porosity and method of application.

CLEAN UP: Clean tools and equipment immediately after each use with soap and water.

CAUTIONS

Keep out of reach of children. Do not take internally. Avoid contact with eyes and mucous membranes and prolonged contact with skin. Avoid breathing mist. Close container tightly after each use. Do not re-use containers. Contains sodium carbonate peroxyhydrate. Do not mix with chlorine bleach or other chemicals. Store in original container only. Sweep up spills and flush down drain. Contact with combustible organic materials may cause fire. Accumulation of product on ladders, scaffolding, decks, etc., may result in a slippery surface.

FIRST AID

IF INHALED: Move to fresh air. **IF SWALLOWED:** Rinse mouth. Do NOT induce vomiting. Never give an unconscious person anything to drink. Immediately call a POISON CENTER or doctor/physician. Oxygen and/or artificial respiration may be necessary. **FOR SKIN CONTACT:** Remove/Take off immediately all contaminated clothing. Wash off immediately with soap and plenty of water. Get medical attention if irritation persists. **FOR EYE CONTACT:** Immediately flush eyes thoroughly with water for at least 15 minutes, including under the eyelids. Remove contact lenses, if present and easy to do. Continue rinsing. Seek medical attention immediately. In case of difficulty in opening lids, administer an analgesic eye wash (oxybuprocaine).

For additional information for this product, consult the Safety Data Sheet available at www.restore-a-deck.com.

LIMITED WARRANTY

Our recommendations for use of this product are based upon tests believed to be reliable. Since field conditions vary widely, the user must determine the suitability of the product for the particular use and specific method(s) of application. Due to the fact that RAD OPW LLC has no control over surface preparation and application methods, no guarantee as to results is offered, expressed or implied. RAD OPW LLC warrants this product to be free from manufacturing defects. RAD OPW LLC's liability shall be limited in all events to supplying enough product to re-treat the specific areas to which defective product was applied. This warranty does not include the cost of labor application. RAD OPW shall not have any other liability including direct, incidental, or consequential damages. Some states do not allow the exclusion of incidental or consequential damages, so this limitation may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Shelf Life: 36 months

PACKAGING

Available in 2 lbs recyclable plastic bags/containers.

TRANSPORT AND HANDLING

Restore-A-Deck Cleaner is not considered hazardous under Department of Transportation regulations. Do not stack pallets. Store in cool, dry area.