



Portable Air Conditioning Unit Instructions

Each unit comes with

Outflow Hose

Hose Extension

Bucket

Window Attachments

- Attach outflow hose (and extension, if necessary) to back of unit
- Place end of hose outside of room to be cooled
- Place drainage tube in bucket
- Turn on A/C unit
- Use “mode” button to select cool
- Set temperature using up and down arrows
- Use fan button to choose fan speed
- “Turbo” will allow the unit to reach desired temperature in the shortest amount of time
- “Swing” button controls the direction of the air – each press moves the vent 6 degrees up or down
- **Check bucket periodically to avoid overflow**