

Application Note

AN #: 210

DATE: 09-Jun-00

Page 1 of 1

PYRAMID MODEL #: SVR-200 / SVR-250

RADIO MODEL: Sercuricor 4115

ENGINEER: W. Carlin

APPROVAL INITIALS

ENGINEER _____

DEPT. HEAD _____

Connections:	SVR	Function	Radio
	Black/Shield	Ground	All points reference SPU circuit board
	White	Tx Audio Out	D3 Anode (Chassis Ground)
	Blue	Remote enable/disable	Junction R178/R179
	Green	PTT Out	External Switch to Ground
	Red	Switched B+	R47
	Yellow	Rx Audio In	Q3 Drain
	Violet	COR	Q13 Drain (Chan Rx)
	Brown	Local Mic In	Pin 13 of U28
	Grey	On Air Detect	N/C
			R72 (RF PA Enable)

SVR Jumpers:	JP1	[-]	Remote Enable
	J1	[Out]	Tx audio level
	J2	[In]	Tx audio impedance
	J4	[In]	Local mic audio loop
	J5	[Out]	Local mic PTT loop
	J6	[Out]	Local mic Sensitivity
	J7	[In]	Rx Sensitivity
	J8	[+]	Pull up resistor
	J9	[Out]	MCOR pull up resistor

SVR Program:	Mobile COR Polarity:	High
	Mobile Type:	Trunking
	On-Air Polarity:	High
	Tx Audio Response:	De-emp
	Rx Audio Response:	Pre-Emp

Additional Modifications (SVR-200 / SVR-250):

1. None

Additional Modifications (Radio):

1. Drill a hole in the rear or top panel of the 4115 mobile to run the interface cable into the unit. Secure the cable with strain relief.