

Application Note

AN #: 256

DATE: 17-Jan-06

Page 1 of 1

PYRAMID MODEL #: SVR-200 / SVR-250

RADIO MODEL: Motorola XTL-5000 High Power/w Millennium Control

ENGINEER: C. Carbajal

APPROVAL INITIALS

ENGINEER _____

DEPT. HEAD _____

Connections:	SVR	Function	Radio
	Black/Shield	Ground	Accy Pin 18 (Ground)
	White	Tx Audio Out	Accy Pin 8 (TX_Audio)
	Blue	Remote enable/disable	External Switch To Ground
	Green	PTT Out	Accy Pin 1 (PTT)
	Red	Switched B+	Accy Pin 22 (SW B+)
	Yellow	Rx Audio In	Accy Pin 9 (DET_Audio)
	Violet	COR	Accy Pin 16 (SPARE 1) * See Notes
	Brown	Local Mic In	Accy Pin 12 (Mic_Hi)
	Grey	On Air Detect	Accy Pin 17 (SPARE 2) * See Notes

SVR	JP1	[-]	Remote Enable	SVR	Mobile COR Polarity:	High
Jumpers:	J1	[Out]	Tx audio level	Program:	Mobile Type:	Conv/Trunk
	J2	[Out]	Tx audio impedance		On-Air Polarity:	High
	J4	[Out]	Local mic audio loop		Tx Audio Response:	De-Emp
	J5	[Out]	Local mic PTT loop		Rx Audio Response:	Pre-Emp
	J6	[Out]	Local Mic Sensitivity		Local Mic Repeat	Enabled
	J7	[Out]	Rx Sensitivity			
	J8	[+]	Pull up resistor			
	J9	[Out]	MCOR Pull up resistor			

Additional Modifications (SVR-200/SVR-250):

Additional Modifications (Radio):

1. On the HLN1454B Remote Interconnect Board, remove JU353, R350 and R356.
2. Run a jumper wire from Pin 16 of the J60 Accessory Connector to the collector of Q0200 on the HUD4025B logic PCB. (COR)
3. Run a jumper wire from Pin 17 of the J60 Accessory Connector to the base of U3560. (On Air Detect)
4. In the Astro Mobile CPS, program the **Radio Wide / Adanced** menu options to:
 - a. **Aux PTT Audio Source = Aux_TX**
 - b. **Aux Transmit Sensitivity = 300mV**

Note: In order to run the jumper wires for COR and On Air Detect, you will need to drill or cut notches in the XTL-5000 chassis to avoid pinching jumper wires to ground. All jumper wires are run on the bottom of the main control board HUD4025B.