

# Application Note

AN #: 263B

DATE: 21-Sep-2018

Page 1 of 1

**PYRAMID MODEL #:** SVR-200 / SVR-500 / SVR-250 / SVR-300

**RADIO MODEL:** Tait TM8200 MPT

**ENGINEER:** C. Carbajal

**APPROVAL INITIALS**

ENGINEER

DEPT. HEAD

Connections:	SVR	Function	Radio (Auxillary Connector DB15)
	Black/Shield	Ground	Pin 15
	White	Tx Audio Out	Pin 7
	Blue	Remote enable/disable	Pin 9
	Green	PTT Out	Pin 12
	Red	Switched B+	Pin 8
	Yellow	Rx Audio In	Pin 13
	Violet	COR	Pin 2
	Brown	Local Mic In	N/C
	Grey	On Air Detect	Pin 10 (Not Connected In Factory Cable)
	Black/White	Emergency	Pin 5 (SVR-250/300 ONLY)

<b>SVR</b>	JP1	[-]	Remote Enable	<b>SVR</b>	Mobile COR Polarity:	Low
<b>Jumpers:</b>	J1	[Out]	Tx audio level	<b>Program:</b>	Mobile Type:	Conv.
	J2	[Out]	Tx audio impedance		On-Air Polarity:	---
	J4	[Out]	Local mic audio loop		Tx Audio Response:	Pre-Emp
	J5	[Out]	Local mic PTT loop		Rx Audio Response:	De-Emp
	J6	[Out]	Local Mic Sensitivity		Priority Sampling	~ 0.75 Sec.
	J7	[Out]	Rx Sensitivity		Local Mic Repeat	Disabled
	J8	[+]	Pull up resistor			
	J9	[In]	MCOR Pull up resistor			

**Note:** Pyramid offers a universal Tait TM Series interface cable P/N 7500-10-1011 (SVR-200) and 7500-10-1210 (for SVR-250/300). These cables do not have On-Air Detect wired, which is used for Pyramid Smart Trunking operation. These cables have 3 wires coming out of the DB-15. Orange=Ignition Sense, Red = 12V Output from the radio accy connector, Black = GPIO4, which can be used to enable an external accessory, such as a horn relay or as an input.

## Additional Modifications (Radio):

1. In the TM8200 Programming Application:
  - a. In the **Global Parameters / Programmable I/O / Digital** screen
    1. Set AUX\_GPI1, Mode = All, Direction = Input, Action = External PTT 1, Active = Low
    2. Set AUX\_GPIO4, Mode = All, Direction = Output, Action = Transmission Status, Active = Low
    3. Set AUX\_GPIO5, Mode = All, Direction = Output, Action = Call Setup Status/Radio Idle, Active = High
    4. Set AUX\_GPIO6, Mode = All, Direction = Output, Action = F3 Key Status, Active = High, Signal = Latching
    5. Set AUX\_GPI2, Mode = All, Direction = Input, Action = Enter Emergency Mode, Active = Low
  - b. In the **Global Parameters / Programmable I/O / Audio** screen
    1. Set RX/PTT Type **RX**, Tap Out = R10, Tap Out Type = D, Tap Out Unmute = Except on PTT
    2. Set RX/PTT Type **EPTT1**, Tap In = T3, Tap In Type = A, Tap In Unmute = On PTT
  - c. In the **Trunked Features and/or Conventional Features / Key Settings** screen
    1. Program one desired key = Action Digital Output Line. This will set one key as the remote enable of the SVR
  - d. In the **Global Parameters / PTT / External PTT (1)** screen
    1. Enable PTT Press Call Setup
    2. Enable Single Press PTT MPT Call
    3. Audio Source = Audio Tap In