

Application Note

AN #: 317

DATE: 28-Dec-17

Page 1 of 1

PYRAMID MODEL #: SVR-200 / SVR-250 / SVR-300

RADIO MODEL: Kenwood NX-3720 / NX-3820

ENGINEER: C. Carbajal

APPROVAL INITIALS

ENGINEER

DEPT. HEAD

Order the Pyramid interface cable Part # 7502-10-1212 for SVR-250/300 Series

Connections:	SVR	Function	Radio	DB15HD Connector
	Black/Shield	Ground	Pin 15	Ground
	White	Tx Audio Out	Pin 5	MI2
	Blue	Remote enable/disable	Pin 10	Aux I/O 10
	Green	PTT Out	Pin 9	Aux I/O 9
	Red	Switched B+	Pin 1	SB+
	Yellow	Rx Audio In	Pin 4	AFO
	Violet	COR	Pin 8	Aux I/O 8
	Brown	Local Mic In	N/C	
	Grey	On Air Detect	Pin 11	Aux I/O 11

SVR	JP1	[-]	Remote Enable	SVR	Mobile COR Polarity:	High
Jumpers:	J1	[In]	Tx audio level	Program:	Mobile Type:	Conv/Trunk
	J2	[In]	Tx audio impedance		On-Air Polarity:	High
	J4	[In]	Local mic audio loop		Tx Audio Response:	De-Emp
	J5	[Out]	Local mic PTT loop		Rx Audio Response:	Pre-Emp
	J6	[In]	Local Mic Sensitivity		Local Mic Repeat	Yes
	J7	[Out]	Rx Sensitivity			
	J8	[+]	Pull up resistor			
	J9	[Out]	MCOR Pull up resistor			

Additional Modifications (SVR-200 / SVR-250 / SVR-300): Ensure J11 is [In]

Additional Modifications (Radio):

1. Move R659 to R601 on the RF deck of the Kenwood. This enables the MI2 at pin 5 of the DB15.
2. Move R613 to R612 on the RF deck of the Kenwood. This enables AFO at pin 4 of the DB15.
3. In the **Key Assignment** menu set one of the soft keys for **AUX A** to enable the repeater.
4. In the **Extended Function/AUX Tab** set the following:
 - a. DB-15HD 8 Pin = Output, TOR, High
 - b. DB-15HD 9 Pin = Input, Ext PTT (Voice), Low
 - c. DB-15HD 10 Pin = Output, AUX A, Low
 - d. DB-15HD 11 Pin = Output, TXS, High
5. In the **Extended Function/Modulation Line Tab** set the following:
 - a. MIC PTT: Mic Line = Connect, MI2 line = Connect, DI Line = Disconnect, QT = Yes, STE = Yes
 - b. External PTT (Voice): Mic Line = Disconnect, MI2 line = Connect, DI Line = Disconnect, QT = Yes, STE = Yes