

Application Note

AN #: 147D

DATE: 21-Jun-06

Page 1 of 1

PYRAMID MODEL #: SVR-200 / SVR-250

RADIO MODEL: Kenwood TK-x30 Single/Dual Control Head

ENGINEER: W. Carlin

APPROVAL INITIALS

ENGINEER

DEPT. HEAD

Order the Pyramid TK-x30 interface cable Part # 7500-10-1044 for the SVR-200

Order the Pyramid TK-x30 interface cable Part # 7500-10-1244 for the SVR-250

Connections:	SVR	Function	Radio
	Black/Shield	Ground	J4 Pin 15
	White	Tx Audio Out	J4 Pin 5
	Blue	Remote enable/disable	J4 Pin 10
	Green	PTT Out	J4 Pin 8
	Red	Switched B+	J4 Pin 7
	Yellow	Rx Audio In	J4 Pin 4
	Violet	COR	J4 Pin 11
(Optional)	Brown	Local Mic In	J4 Pin 1
	Grey	On Air Detect	N/C

SVR	JP1	[-]	Remote Enable	SVR	Mobile COR Polarity:	High
Jumpers:	J1	[In]	Tx audio level	Program:	Mobile Type:	Conv.
	J2	[In]	Tx audio impedance		On-Air Polarity:	Low
	J4	[Out]	Local mic audio loop		Tx Audio Response:	De-emp
	J5	[In]	Local mic PTT loop		Rx Audio Response:	Flat
	J6	[Out]	Local Mic Sensitivity			
	J7	[Out]	Rx Sensitivity			
	J8	[+]	Pull up resistor			

Additional Modifications (SVR-200 / SVR-250): None

Additional Modifications (Radio):

1. Program the "A" key for Aux option.
2. Add a jumper from IC103 pin 4 to CN106 pin 9 (HN2).
3. Add a jumper from point "D" to CN106 pin 8 (HN1).
4. If the local mic repeat option is enabled (Brown wire to J4-1), add a jumper from IC103 pin 19 to CN105 pin 2 (HK) and remove R131 on the bottom side of the PCB.
5. On the display front panel PCB, remove R20 (basic control head) or R35 (full alpha) for LED back lighting when repeater is enabled.

Revision Number

Date

Approval Initials